


HS/HW400/600

Exploded parts diagram

Image shown is a 600







Part Number	No.	Description	Qty
***	1	Cabinet	1
***	2	Control Panel	1
X1-LOCK01	3	Door Lock (400/600)	1
X1-SWITCH400	4	Power Switch (400/600)	1
X1-CONTROLLER402	5	Controller (400/600)	1
X1-HINGE07	6	RH Upper Hinge (400/600)	1
X1-HINGE08	7	Spring Hinge (400/600)	2
X1-GASKET400	8	Door Gasket (400)	1
X1-GASKET401	8	Door Gasket (600)	1
***	9	Door (Stainless/White 400/600)	1
X1-HINGE09	10	RH Lower Hinge (400 & 600)	1
***	11	Feet (adj)	2
X1-COND400	12	Condenser (400)	1
X1-COND403	12	Condenser (600)	1
X1-PIPEHP	13	Vaporising Coil (400/600)	1
***	14	Evap. Fan Cover	1
***	15	Fan Cover Support	2
***	16	Fan Cover	1
***	17	Cover	1
***	18	Back Cover	1
X1-COND400	19	Cond. Fan Motor (600)	1
X1-COND400	19	Cond. Fan (400)	1
X1-COMP400	20	Compressor (400)	1
X1-COMP402	20	Compressor (600)	1
R4-DRIER20	21	Drier	1
***	22	Cooling Unit Board	1
***	23	Rollers	2
X1-SENSOR01	24	Sensor	1
***	25	Power Cord	1
X1-FAN03	26	Evap. Fan Motor (400/600)	1
***	27	Evap. Fan Guard	1
X1-EVAP40	28	Evaporator (400)	1
X1-EVAP60	28	Evaporator (600)	1
***	29	Inner Drain Pan	1
***	30	Outer Drain Pan	1
X1-SHELF400	31	Shelf (400)	4
X1-SHELF600	31	Shelf (600)	4
X1-CLIP	32	Clip (400/600)	16
***	33	Ladder rack	4
***	34	Light/Fan switch	1

*** Please contact Spares for assistance***