


LS/LW400/600

Exploded parts diagram

Image shown is an L600







Part Number	Number	Description	Qty
***	1	Cabinet	1
***	2	Control Panel	1
X1-LOCK01	3	Door Lock (400/600)	1
X1-SWITCH400	4	Power Switch	1
X1-CONTROLLER402	5	Controller (400/600)	1
X1-HINGE07	6	RH Upper Hinge	1
X1-HINGE08	7	Spring Hinge	2
X1-GASKET400	8	Door Gasket (400)	1
X1-GASET401	8	Door Gasket (600)	1
***	9	Door (Stainless/White 400/600)	1
X1-HINGE09	10	RH Lower hinge (400/600)	1
***	11	Feet (adj)	2
X1-COND404	12	Condenser 1 (400)	1
X1-COND405	13	Condenser 2 (400)	1
X1-COND404	12	Condenser 1 (600)	1
X1-COND405	13	Condenser 2 (600)	1
X1-EVAPFASTEN	14	Evap. Fasten (600)	10
***	14	Evap. Fasten (400)	10
***	15	Evap. Bracket	5
X1-EVAP400	16	Evaporator (400)	1
X1-EVAP600	16	Evaporator (600)	1
***	17	Cover	1
***	18	Back Cover	1
***	19	Cond. Fan Motor (400/600)	1
X1-COMP401	20	Compressor	1
X1-COMP600	20	Compressor	1
R4-DRIER20G	21	Drier	1
***	22	Cooling Unit Board	1
***	23	Rollers	2
X1-SENSOR01	24	Sensor	1
***	25	Power Cord	1

Please contact Spares for assistance